



Rain Cover for Canon EOS C100

SKU: SR400

Sachtler Bag Rain Cover for Canon C100



PRODUCT DESCRIPTION

- One-piece design
- Constructed of transparent polyurethane (serviceable up to -20C) and waterproof nylon for maximum visibility
- Fast and easy access to all camera features
- Quick to install while shooting supporting your workflow
- Hotshoe connector in the cover's rigid front hood section anchors and stabilizes the cover to the camera
- Option to work with the camera's flip-out LCD screen open
- Exterior 6" ABS track allows for addition of mini light while raincover is in use

TECHNICAL SPECIFICATIONS

Weight	0.42 kg 0.93 lb
Height	33 cm to 12.99 in to
Bag Type	Rain Cover
Wheels	No
Light	No

YOU MAY ALSO LIKE...



[Dr. Bag - 1](#)